

# valken

## Reflex Red Dot Sight RDA05



**Caution:** Before mounting your reflex sight, be sure to read carefully the operating instructions of the sight. Be sure that your gun is NOT loaded before you attempt to install your sight. Always follow safe gun handling procedures.

- Always keep muzzle pointed in a safe direction
- Gun should be unloaded when not in use.
- Be sure of your target and what is beyond it.
- Always wear eye and ear protections when shooting.
- Familiar yourself with the gun you are using.

### Installing battery

The sight uses one 3V CR2032 (or equivalent) Lithium button cell. Open the battery compartment using a small blade screwdriver to push inward the small tab and pull the battery tray out. Install the coin battery into the cavity of the tray with + side facing up and then insert the tray into the compartment with the battery facing the bottom of the sight and be sure the tray is fully inserted and locked in place. **Always remember to carry a spare battery with the sight.**



### Mounting the sight

RDA05 has integral rail mount at the bottom of the sight with a single clamping bolt. It fits onto picatinny and weaver style scope bases. Clamp the rail mount onto scope base on the gun and move the sight back and forth to adjust for desired placement. Be sure to leave sufficient clearance (min. 3inches) between your eye and the end of the sight. Be sure to let the clamping bolt rest against the front side of the crosscut or ring slot on the scope base. Tighten the clamping bolts to securely hold the sight in place.

### Power ON/OFF and Red Dot Intensity Adjustment

Turn the sight ON by making one push on the power button on the side of lens hood. A small red dot of 3.5moa should be visible in the field of view looking into the reflex lens. Click push the button to adjust the brightness of the dot to the desired level. Push and hold the button for 4seconds to turn the sight OFF. **ALWAYS MAKE SURE THE SIGHT IS TURNED OFF WHEN FINISHING USE OF THE SIGHT.**

**Caution:** Since Zeroing involves actual shooting, it should be done at an approved shooting range or equally safe area. Be sure to use eye and ear protection when shooting.

### Windage and Elevation Adjustments

Windage and elevation screws are at the back of the sight with arrows marked to show the direction to which the point of impact is moved when making adjustment. Use a small blade type watch screw driver to adjust point of impact by turning the screws in the direction as needed.

### Storage

Always keep the sight in clean and dry place. When the sight is not going to be used for long period of time, take out the battery from battery tower. Should the lens get dusty or dirty, use soft lens cloth to wipe it clean